Interactive Adapter search: www.mactoolsradiatortools.com

COOLING SYSTEM ADAPTERS and COOLING SYSTEM TOOLS APPLICATION GUIDE and **PARTS LIST** for **CST500** Includes 3 Most Commonly Required **Cooling System Adapters MAR100** Coolant Retainer and Pressure Tester **Higher Vacuum!** Faster, more complete fill! **CSR202** For Use with Positive Fit Cooling System Adapters

CSR302 No Adapters Required!



COOLING SYSTEM TOOLS FOR LARGE TRUCKS



CSR400 Truck Refiller sized specifically for large trucks

CSR400 Large Truck Refiller

- New higher capacity generator creates a high vacuum quickly.
- Larger internal passageways to move more coolant faster
- Longer and larger hoses improve coolant flow
- Faster, more complete fill on larger systems



CST300 Large Truck Cooling System Pressure Tester:

1. Pressure pump uses shop air to generate pressure in large truck cooling systems EFFORTLESSLY!

2. Set includes 3 adapters to pressure test pressure relieving caps found on large trucks. The UCT700-6 cap adapter tests caps from "A" size (2 3/16" O.D.) filler necks. The RCA14504 cap adapter tests caps from "B" size (2 11/16" O.D.) filler necks. The RCA1C035 cap adapter tests caps with a 52mm x 2.5mm thread.

Combine CST300 with CSA600 for complete truck cooling system testing with no duplications.

CSA600 Large Truck Cooling System Adapter Set:

Compatible with most cooling system pressure tester pumps. Includes 6 cooling system adapters:

- (1) RA14505
- (2) RA10036
- (3) RA10027 NOTE: Plastic box available
- (4) RA10022 separately #CSA600PB
- (5) RA10054
- (6) RA10032





Thread Cutaway

APPLICATION:


AUDI®: models with male threads on filler neck PORSCHE®: Boxster: 1997-2006 Cayman: 2006 911: 2000-2012 SMART CAR®: Models 2008-2015 VOLKSWAGEN®: models with male threads on filler neck of radiator or expansion tank-pre 1990.

RA10025



RCA1C026






WHERE GASKET OF CAP SEALS ON

Thread Cutawav

APPLICATION:

FERRARI®/MASERATI®: most models 2000-current JEEP®: models with male threads on filler neck (1990-1994) RENAULT®: (1985-1997) SAAB® 900: (1978-1993) -900 Convertible (1994) -9000 (1986-1998) STERLING®: (1987-1991) VOLVO®: most models through 2007 with threaded neck (see page 18)



Most models with female threads on filler neck 1990-1998

RA10032




COOLANT BOTTLE NECK **Outside Diameter** - 52 mm -


Thread Cutaway


APPLICATION:

Some models of Buick®, Cadillac®, Chevrolet®, Ford®, Freightliner®, GMC®, International®, Infiniti®, Isuzu®, Jaguar®, Kenworth®, Land Rover®, Lincoln®, Mazda®, Mercedes®, Mercury[®], Nissan[®], Oldsmobile®, Peterbilt® and Pontiac®



Thread Cutaway












PAGE 6






MOST ASIAN VEHICLES - MOTORCYCLES - FORKLIFTS - TOYOTA® SIENNA VAN



Comments: The RA10128/RCA1C029 and the RA10138/RCA1C039 have applications too numerous to list here. See Application Guide pp 12-18. These adapter sets are quite similar, but the RA10128/RCA1C029 is a deeper neck than the RA10138/RCA1C039. See drawings above, right.


Note: RA10128 AND RA10138 are shaped to resemble caps from system to be tested.



APPLICATION:

Most passenger vehicles through the mid 1980's have this radiator neck and many still do today. This is the configuration onto which the pump attaches directly.

LARGE TRUCKS / BUSES / HEAVY EQUIPMENT



LARGE TRUCKS / BUSES / HEAVY EQUIPMENT



Interactive Adapter search: www.mactoolsradiatortools.com

COOLINO	JIJILI	
Make/Model/Year	Cooling System Adapter	Cap Adapter
ACURA®		
Models with 16mm deep filler neck, see page 9	RA10128	RCA1C029
Models with 9.5mm deep filler neck, see page 9	RA10138	RCA1C039
ALFA ROMEO®		
Some models 2014-current	RA10072**	RCA1CO26
ASTON MARTI	V®	
6.0L, V-12		
2015-current	RA10052	RCA1C05
Various Models		
2005-current	RA10046	RCA1CO47
AUDI®		
Models with male threads		
on filler neck of exp. tank	RA10022	RCA1C023
Models with female threads		
on filler neck of exp. tank	RA10041	RCA1CO40
BLUEBIRD® BUS		
Late model Thomas Built		
buses	RA10036	RCA1C035
10505	10000	Refreudd
BMW®		
Models with threaded		
filler neck		
Up to 1987	RA10245	RCA1CO47
1988 & Newer,		
(except as noted)	RA10345	RCA1C346
Most models after 2006 Model 325	RA10445	RCA1C446
Model 325 1988-1991	RA10245	RCA1C047
Model 535	KA1024J	KCA1C047
1989-1993	RA10245	RCA1C047
5&6 Series	INTO245	KCATCOT/
2005-current	RA10445	RCA1C446
1 Series	NIT OF TO	Kerrerio
2008-current	RA10445	RCA1C446
3 Series		
1990-2006	RA10345	RCA1C346
2005-current	RA10445	RCA1C446
Turbocharger cooling sys (all)	RA10063	RCA1C026
5 Series		
1998-2004	RA10345	RCA1C346
2005-current	RA10445	RCA1C446
Turbocharger cooling sys (all)	RA10063▲	RCA1C026
6 Series		
2004-current	RA10445	RCA1C446
Turbocharger cooling sys (all)	RA10063▲	RCA1CO26
7 Series	DA10345	DCA1C244
1994-2008	RA10345 RA10445	RCA1C346 RCA1C446
2008-current Turbocharger cooling sys (all)		RCA1C446 RCA1C026
ioi nocitai dei coollitid sàs (all)		NCATCOZO

Make/Model/Year	Cooling System Adapter	Cap Adapter
BMW®		
X1 2009-2011	RA10345	RCA1C346
X3 2004-7/2009 7/2009	RA10345 RA10445	RCA1C346 RCA1C446
X5 2000-2008	RA10345	RCA1C346
2009-current Turbocharger cooling sys (all)	RA10445 RA10063▲	RCA1C446 RCA1C026
X6 2008-current Turbocharger cooling sys (all)	RA10445 RA10063▲	RCA1C446 RCA1C026
Z3 2002	RA10345	RCA1C346
Z4 2003-2008	RA10345	RCA1C346
2009-current Z8 2003	RA10445 RA10345	RCA1C446 RCA1C346
		NCAT COTO
BUICK® All Models w/male threads		
All Models W/ male threads on filler neck except as noted below	RA10036*	RCA1C035
Skyhawk 1982-1987 1.8L & 2.0L	RA14503	
Skylark 1982-1988 2.5L 1992-1998	RA14503 RA10036*	RCA1C035
Somerset 1985-1987 2.5L CADILLAC®	RA14503	
All Models w/male threads		
on filler neck except as noted below	RA10036*	RCA1C035
Catera 1997- 2001 STS, CTS, ATS	RA10034	RCA1C047
2005 -current Engine Cooling System Supercharger Cooling System	RA10036 RA10056	RCA1C035 RCA1C057
Seberaria for cooming system		

**RA10025 may also work.

▲ RA10063 seals the same way the radiator cap seals but the RA10025 will work in most applications.

*If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

Interactive Adapter search: www.mactoolsradiatortools.com

COOLING	JIJIEN		EKJ
Make/Model/Year	Cooling System Adapter	Cap Adapter	Make/Model/
CHEVROLET®			CHRYSLER®/D
All Models w/male threads on filler neck except as noted			Pacifica
below	RA10036*	RCA1C035	2017-current
Aveo	KATUUJU	KCATCOJJ	Engine Cooling S Electric Motor
2004-2011	RA10034	RCA1C047	Promaster
Beretta			2014-current
1992-1996	RA10036*	RCA1C035	RAM 50 Pickup
Bolt			1987-1993
2017-current Citation			RAM 1500 with eTo
1982-1985 2.5L	RA14503		2018-current RAM Pickup (some
RA10056	RCA1C057		2013-current
Cobalt			Sebring
2005-2010			2003-2005 6c 3
Engine Cooling System	RA10036	RCA1C035	4c 2.4L
Supercharger Cooling System	RA10056	RCA1C057	2001, 2002-200
Impala 1994-1996	RA10036*	DCA1C025	Sprinter Van 2007-2010
2004-current	RA10036	RCA1C035 RCA1C035	Stealth
Lumina	KATUUJU	KCATCUJJ	1991-1996
1990-1992	RA14503		Stratus (3.0 liter on
Metro			2001-2006
1998-2001	RA10138	RCA1C039	Summit
Nova			1989-1992 1992-1996
1985-1988	RA10128	RCA1C029	Talon
Prizm 1998-2002	RA10138	RCA1C039	1990-1998
Silverado with Duramax	KATUTSO	KCATCU39	DAEWOO
(L5P diesel) engine			All
2017-current (pressure testing)	RA10092		1999-2002
2017-current (vacuum filling)	RA10093		FERRARI ®
Spectrum			Most Models
1985-1989	RA10128	RCA1C029	2000-current
Sprint	B410100	DC41 C000	FIAT ®
1985-1988 Tracker	RA10128	RCA1C029	500
1998-2004	RA10138	RCA1C039	2015-current
Volt	KATO 100	NCHTCOO7	FORD®/LI
2012-current			All Models w/male
Electric Motor	RA10056	RCA1C057	on filler neck except
Battery System	RA10056	RCA1C057	below
Gasoline Engine	RA10036	RCA1C035	Aspire
CHRYSLER®/DODGE®	/EAGLE®/PLYM	OUTH®/RAM®	1994-1997
200			C-Max 2013-current
2015-current	RA10036	RCA1C035	Contour
1500 with eTorque	RA10056	RCA1C057	1995-1997
2018 - current 2000 GTX	KAIUUSO	KLATLUS/	1998-2000
1989-1990	RA10128	RCA1C029	Cougar/Thunderbin
Avenger			1989-1992
1995-1999	RA10128	RCA1C029	1993-1997 V8
Colt			1993-1997 V6
1984-1993	RA10128	RCA1C029	Ecosport
1992-1994 (some models)	RA10138	RCA1C039	2013-current
Conquest 1984-1989	RA10128	RCA1C029	Edge
Crossfire	MATUIZU	NCATCO27	2015-current
2004-2008	RA10044	RCA1C045	Escape
Dart			2001-2012 2012 current
2013-current	RA10036	RCA1C035	2013-current
Laser/Talon	DA10100	DC41C000	* If RA10036 "Ste
1990-1998	RA10128	RCA1C029	neck, the RA100

Make/Model/Year	Cooling System Adapter	Cap Adapter
CHRYSLER®/DODGE@	/EAGLE®/PLYMO	UTH@/RAM®
Pacifica		
2017-current		
Engine Cooling System	RA10036	RCA1C035
Electric Motor	RA10056	RCA1C057
Promaster		
2014-current	RA10072**	RCA1CO26
RAM 50 Pickup		
1987-1993	RA10128	RCA1CO29
RAM 1500 with eTorque		
2018-current	RA10056	RCA1C057
RAM Pickup (some models)		
2013-current	RA10036	RCA1C035
Sebring		
2003-2005 6c 3.0L &	RA10138	RCA1C039
4c 2.4L		
2001, 2002-2006	none	UCT700-6
Sprinter Van	lione	001700-0
2007-2010	RA10058	RCA1C059
Stealth	NA10030	ICATCOJ7
••••	DA10100	BCA1C020
1991-1996 Stratus (2.0 liter enhu)	RA10128	RCA1C029
Stratus (3.0 liter only)	B410100	BC110000
2001-2006	RA10138	RCA1CO39
Summit		
1989-1992	RA10128	RCA1C029
1992-1996	RA10138	RCA1C039
Talon		
1990-1998	RA10128	RCA1C029
DAEWOO®		
All		
1999-2002	RA10034	RCA1C047
FERRARI®	INTO001	KCKTC017
	1	
Most Models		
2000-current	RA10025	RCA1C026
2000-current	RA10025	KLATLUZ6
FIAT ®	RA10025	KCATCU26
FIAT ® 500		
FIAT® 500 2015-current	RA10072**	RCA1C026
FIAT® 500 2015-current FORD®/LINCOL	RA10072**	RCA1C026
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads	RA10072**	RCA1C026
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted	RA10072** N@/MERCUR	RCA1CO26 Y®
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads	RA10072**	RCA1C026
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below	RA10072** N@/MERCUR	RCA1CO26 Y®
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire	RA10072** N@/MERCUR RA10036*	RCA1C026 Y@ RCA1C035
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997	RA10072** N@/MERCUR	RCA1CO26 Y®
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max	RA10072** N@/MERCUR RA10036* RA10128	RCA1C026 Y@ RCA1C035 RCA1C029
FIAT® 500 2015-current FORD@/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current	RA10072** N@/MERCUR RA10036*	RCA1C026 Y@ RCA1C035
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour	RA10072** N©/MERCUR RA10036* RA10128 RA10052	RCA1C026 Y@ RCA1C035 RCA1C029 RCA1C053
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997	RA10072** N@/MERCUR RA10036* RA10128	RCA1C026 Y@ RCA1C035 RCA1C029
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour	RA10072** N©/MERCUR RA10036* RA10128 RA10052	RCA1C026 Y@ RCA1C035 RCA1C029 RCA1C053
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997	RA10072** N©/MERCUR RA10036* RA10128 RA10052 RA10034	RCA1C026 CA1C035 RCA1C029 RCA1C053 RCA1C047
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000	RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10034 RA10046	RCA1C026 CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992	RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10046 RA10128	RCA1C026 TO RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C047 RCA1C029
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8	RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10034 RA10036 RA10036*	RCA1C026 CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8 1993-1997 V6	RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10046 RA10128	RCA1C026 TO RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C047 RCA1C029
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8 1993-1997 V6 Ecosport	RA10072** N©/MERCUR RA10036* RA10128 RA10052 RA10034 RA10046 RA10128 RA10036* RA10128	RCA1C026 CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029 RCA1C029 RCA1C029
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8 1993-1997 V6 Ecosport 2013-current	RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10034 RA10036 RA10036*	RCA1C026 CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8 1993-1997 V6 Ecosport	RA10072** N©/MERCUR RA10036* RA10128 RA10052 RA10034 RA10046 RA10128 RA10036* RA10128	RCA1C026 CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029 RCA1C029 RCA1C029 RCA1C029 RCA1C029
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8 1993-1997 V6 Ecosport 2013-current	RA10072** N©/MERCUR RA10036* RA10128 RA10052 RA10034 RA10046 RA10128 RA10036* RA10128	RCA1C026 CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029 RCA1C029 RCA1C029
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V6 Ecosport 2013-current Edge	RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10036* RA10036* RA10036* RA100352	RCA1C026 CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029 RCA1C029 RCA1C029 RCA1C029 RCA1C029
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8 1993-1997 V6 Ecosport 2013-current Edge 2015-current	RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10036* RA10036* RA10036* RA100352	RCA1C026 (CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029 RCA1C053 RCA1C053 RCA1C053
FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8 1993-1997 V8 1993-1997 V6 Ecosport 2013-current Edge 2015-current Escape	RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10036* RA10036* RA10032 RA10052 RA10052	RCA1C026 CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029 RCA1C029 RCA1C029 RCA1C029 RCA1C029

* If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

**RA10025 will work in most applications

Cooling System Cap Make/Model/Year Adapter Adapter FORD®/LINCOLN®/MERCURY® Fscort/Tracer 1991-2012 RA10128 RCA1C029 Explorer/Mountaineer/Aviator 1995-2002 RCA1C029 RA10128 2002-current RA10036* RCA1C035 F Series pick-up 2015-current RA10052 RCA1C053 Festiva 1988-1993 RA10128 RCA1C029 Fiesta 2011-current RA10052 RCA1C053 Focus RCA1CO47 2000-2004 RA10034 2005-2007 RCA1C035 RA10036* 2008-2011 RA10128 RCA1C029 2012-current RA10052 RCA1C053 Fusion RA10036* 2006-2012 RCA1C035 2013-current RA10052 RCA1C053 15 RA10034 RCA1C047 2002-2006 МКС RCA1C053 2015-current RA10052 Mustang V8. 1996-2014 RA10036* RCA1C035 V6, 1997-2004 RA10128 RCA1C029 V6, 2005-2014 RA10036* RCA1C035 V6 and V8 2015-current RA10052 RCA1C053 Prohe 1989-1997 RA10128 RCA1C029 Ranger Pickup 1995-current (non threaded neck) RCA1C029 RA10128 2002-current RA10036* RCA1C035 (threaded neck) Tempo/Topaz 1992-1994 RA10128 RCA1C029 Thunderbird RCA1C029 1989-1993 (All) RA10128 RA10128 RCA1C029 1994-1997 (V6) 1994-1997 (V8) RA10036* RCA1C035 RA10036* RCA1C035 2002-2004 (V8) Transit Connect 2010-2012 RA10034 RCA1C047 2013-current RA10052 RCA1C053 Villager 1993-2002 RA10128 RCA1C029 Windstar 1995-2000 RA10128 RCA1C029 2000-2003 RA10036* RCA1C035 ZX2 2001-2003 RA10128 RCA1C029

Interactive Adapter search: www.mactoolsradiatortools.com

www.i		latortools.com
Make/Model/Year	Cooling System Adapter	Cap Adapter
FREIGHTLINER ®		
Trucks with: 60mm x 3mm male thread 52mm x 2.5mm male thread Cascadia	RA10054	
2007-current Century, Columbia	RA10032	RCA1C035
2002-current	RA10036	RCA1CO35
GEO®		
Metro		
1989-1994	RA10128	RCA1C029
1995-1998	RA10138	RCA1CO39
Prizm		
1989-1992	RA10128	RCA1C029
1993-2002	RA10138	RCA1C039
Storm		
1990-1993	RA10128	RCA1C029
Tracker		
1989-1993	RA10128	RCA1C029
1994-2004	RA10138	RCA1C039
GMC®		
All Models w/male threads		
on filler neck	RA10036	RCA1C035
Sierra w/ Duramax engine		
2017-current (pressure testing)	RA10092	
2017-current (vacuum filling)	RA10093	
HONDA®		
Models with 16mm deep	RA10128	RCA1C029
filler neck, see page 9	KATUTZU	KCATCO27
	DA10100	DC41C020
Models with 9.5mm deep	RA10138	RCA1C039
filler neck, see page 9		
HUMMER®		
All Models w/male threads		
on filler neck	RA10036	RCA1C035
HYUNDAI®		
Models with 16 mm deep		
filler neck, see page 9	RA10128	RCA1C029
Models with threaded		
filler neck	RA10086	RCA1C087
INDUSTRIAL		
Various industrial		
applications (see page 11 for specs)	RA10090	
INTERNATIONA		l
466 Engine with male		
threads on filler neck 1994-1998	PA10022	RCA1C035
1774-1770	RA10032	NCAT CUSD

* If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

COOLING	JIJILI	ADAFI
Make/Model/Year	Cooling System Adapter	Cap Adapter
INFINITI®		
All Models with Non-Threaded		
Small Cooling System Caps		
(see page 9)	RA10128	RCA1C029
QX30		
2017-current	RA10044	RCA1C045
QX50		
2019 - current	RA10063	RCA1C026
QX56		
2004-2009	RA10036*	RCA1C035
2010-current	RA10128	RCA1C029
ISUZU®		
All models except as		
noted below 1985-2009	DA10120	RCA1C029
Amigo	RA10128	KLATLUZ9
1999-2000 (L-4 only)	RA10138	RCA1C039
Ascender		
2002-2009	RA10036	RCA1C035
i280		
2006	RA10036	RCA1C035
i290	RA10036	RCA1C035
2007-2008 i350	KA10030	KLATLUSS
2006	RA10036	RCA1C035
i370	NAT OUCO	Real Coop
2007-2008	RA10036	RCA1C035
Oasis		
1996-1999	RA10138	RCA1C039
Rodeo	RA10138	RCA1C039
1998-2003 (L-4 only)	KATUT30	KCATCU37
JAGUAR®		
Models with male threads on filler neck		
1990-1994	RA10034	RCA1C047
E-Pace	10001	KCHTCO17
2018-current	RA10052	RCA1C053
F-Type		
2013-current	RA10036	RCA1C035
XF 2009-current	RA10036*	RCA1CO35
XK8 1997-2004, 2006	RA10046	RCA1C047
XK8	1410040	NCATCOM/
1998-2003	RA10046	RCA1C047
2004-2009	RA10036*	RCA1C035
S-Type		
2000-2008	RA10036*	RCA1CO35
X-Type 2009-current	RA10034	RCA1C047
	KA10034	KUATU04/
JEEP®		
Models with male threads		
on filler neck 1987-1990	RA10025	RCA1C026
Cherokee	1.410025	
2014-current	RA10036	RCA1C035
Renegade		
2015-current	RA10036	RCA1C035
Wrangler	BA10026	DCA1C025
2018-current with eTorque	RA10036	RCA1C035
2018-current	RA10056	RCA1C057
* If DA 10024 "Share" with		

* If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

Interactive Adapter search: www.mactoolsradiatortools.com

	lactoolsraald	itortools.com
Make/Model/Year	Cooling System Adapter	Cap Adapter
JOHN DEERE® T	RACTORS	
Most model #'s over 3000		
with 48mm O.D. male		
threads on filler neck	RA10022	RCA1CO23
Some model #'s over 3000		
with 52mm O.D. male		
threads on filler neck	RA10102	N/A
Some Models	RA10102	
KENWORTH® TH	UCKS	
Some Models 2007-current	RA10032	RCA1C035
T270, T370	NAT 0002	NCAT COUS
2015-current	RA10084	
T660	NAT OUT	
2008-2017	RA10042	
T680	10110012	
2014-current	RA10042	
	1410072	
Models with 16mm deep filler neck, see page 9	RA10128	RCA1C029
Sportage	NATU120	NCAT CU27
2016-current	RA10086	RCA1C087
Niro		
2017-current	RA10086	RCA1C087
LAND ROVER®		
Defender		
1993-1995, 1997	RA10034	RCA1CO47
Discovery		
1998	RA10034	RCA1CO47
1999-2004	RA10345	RCA1C346
Freelander 2002-current	RA10025	RCA1C026
LR2	KATOUZJ	KCATC020
2008-current	RA10052	RCA1C053
LR3		
2005-current	RA10036*	RCA1CO35
LR4		
2010-2016	RA10036*	RCA1CO35
Range Rover	DA10004	DCA1C047
1988-1994 1995-2005	RA10034 RA10345	RCA1C047 RCA1C346
2006-2015	RA10345	RCA1C035
Range Rover Evoque		
2012-current	RA10052	RCA1C053
Velar		
2018-current	RA10032	RCA1C035
LEXUS®		
Models with 16mm deep		
filler neck, see page 9	RA10128	RCA1C029
Models with 9.5mm deep filler neck, see page 9	PA10129	PCA1(020
Models with Threaded Caps:	RA10138	RCA1C039
GS 460		
2008-2011	RA10048	RCA1C049
HS 250h		
2010-current	RA10048	RCA1C049
IS F		
2008-2014	RA10048	RCA1CO49
LS 2007 current	RA10048	RCA1C049
2007-current NX	NA10040	KCATCU49
2015-current	RA10048	RCA1C049
2010 (011011		

COOLING	SISIEN	A ADAPI
Make/Model/Year	Cooling System Adapter	Cap Adapter
LIEBHERR® CRA	ANE	
Some models	RA10076	
MACK®		
Late models with male		
threads on filler neck	RA10022	RCA1C023
MASERATI®	INTOULL	RGITCOLO
Most Models		
2000-current	RA10025	RCA1C026
Ghilbi S Q4	KATO025	KCATCO20
2015-current	RA10072**	RCA1C026
MAZDA®		
Models with 16mm deep		
filler neck, see page 9	RA10128	RCA1C029
Models with 9.5mm deep		
filler neck, see page 9	RA10138	RCA1C039
Models with Threaded Caps: B2300 Pickup		
1994-1997	none	UCT700-6
2001-2009	RA10036*	RCA1C035
Tribute		
2001-2011	RA10046	RCA1CO47
Mazda 3 2004-current	RA10052	RCA1C053
Mazda 6	KATUUJZ	KCATCUJ3
2003-current	RA10036	RCA1C035
McLAREN®		
MocLAREN®		
2012-current	RA10072	RCA1C026
MERCEDES®		
Models with threaded neck		
except M-Class below	RA10044	RCA1C045
A-Class		
2019-current	RA10058	RCA1C059
B-Class		
2015-current	RA10058	RCA1C059
M-Class with threaded neck		
1998-2005	RA10036*	RCA1C035
M-Class		
2006-current	RA10044	RCA1C045
Sprinter	D410050	DC416050
2011-current	RA10058	RCA1C059
2019-current	RA10044	RCA1C045
MERKUR®		
Scorpio		
1987-1989	RA10245	RCA1CO47
MINI®		
Cooper S Model	DA100/0	DCA1(00)
2002-current	RA10063▲	RCA1C026
MITSUBISHI®		
Models with 16mm deep		
fillen medie en 🛛 🔿 📩	DA10100	DCA1C000
filler neck, see page 9 Models with 9 5mm deen	RA10128	RCA1C029
filler neck, see page 9 Models with 9.5mm deep filler neck, see page 9	RA10128 RA10138	RCA1C029 RCA1C039

 \blacktriangle RA10063 seals the same way the radiator cap seals but the RA10025 will work in most applications.

Interactive Adapter search: www.mactoolsradiatortools.com

	www.mactoolsradiatorfools.com		
Make/Model/Year	Cooling System Adapter	Cap Adapter	
NISSAN®			
All models with non-threaded			
small cooling system caps			
1987-current	RA10128	RCA1C029	
Armada/Titan			
2004-2009	RA10036*	RCA1C035	
2010-2015	RA10128	RCA1CO29	
Kicks			
2019-current	RA10063	RCA1C026	
Rogue Sport			
2017-current	RA10063	RCA1C026	
OLDSMOBILE®			
Achieva			
1992-1998	RA10036*	RCA1C035	
Alero	10000	REATEDOD	
1999-2004	RA10036	RCA1C035	
Aurora			
1995-1999	RA10036*	RCA1C035	
Bravada			
2002-2004	RA10036	RCA1C035	
Cutlass			
1997-1998	RA10036*	RCA1C035	
1999-2004	RA10036	RCA1C035	
Intrigue			
1999-2002	RA10036*	RCA1C035	
PETERBILT® TR	ICVS		
Some Models 2007-current	RA10032		
PONTIAC®			
Fiero			
1984-1988	RA14503		
Firebird			
1999-2002	RA10036	RCA1C035	
G3		B 4 1 4 6 4 7	
2009-2010	RA10034	RCA1CO47	
G5			
2007-2012	RA10036	RCA1C035	
G6	B11000/	BC110005	
2005-2010	RA10036	RCA1C035	
Grand Am	DA14500		
1985-1988	RA14503	DC41C005	
1992-2005 Grand Priv	RA10036*	RCA1C035	
Grand Prix	PA10024	RCA1C035	
2004-2008 GTO	RA10036	NCATCU35	
2004-2008	RA10036*	RCA1C035	
Le Mans	NA10030	NCM10000	
1988-1993	RA10034	RCA1C047	
Montana	NA10034	NCA1 (04/	
1999-2006	none	UCT700-6	
2007-2009	RA10036	RCA1C035	
Optima	10110000		
1988-1991	RA10036*	RCA1C035	
Solstice			
2006-2009	RA10036	RCA1C035	
Sunbird			
1982-1992	RA14503		
Sunburst			
1985-1988	RA10128	RCA1C029	
Sunfire			
1995-1998	RA10036*	RCA1C035	
1999-2005	RA10036	RCA1C035	
Vibe			
2003-2013	RA10138	RCA1C039	
2000 2010			

* If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

**RA10025 will work in most applications

Interactive Adapter search: www.mactoolsradiatortools.com

COOLING	JIJIEN	
Make/Model/Year	Cooling System Adapter	Cap Adapter
PORSCHE®		
911 1999-current Boxster 1997-2006 2007-2013 2015-current	RA10022 RA10022 RA10041 RA10078	RCA1C023 RCA1C023 RCA1C040
(in luggage compartment) Cayenne 2003-current Cayman 2006 2007-2011 2014-current	RA10041 RA10022 RA10041 RA10078	RCA1CO40 RCA1CO23 RCA1CO40
(in luggage compartment) Macan 2015-current Panamera 2010-current	RA10041 RA10041	RCA1CO40 RCA1CO40
RENAULT®		
All models 1985-1987 ROLLS ROYCE®	RA10025	RCA1C026
Ghost 2010 Engine cooling system Supercharger cooling system	RA10445 RA10063	RCA1C446 RCA1C026
SAAB®		
900 1978-1993 1994-1998 900 Convertible 1994 9000 1986-1998 9-3 1999-2003 2004-2011 9-5 1999-2008 9-7X 2005-2009	RA10025 RA10034 RA10025 RA10025 RA10034 RA10036 RA10034 RA10036*	RCA1C026 RCA1C027 RCA1C026 RCA1C026 RCA1C027 RCA1C035 RCA1C047 RCA1C035
SATURN®		
All models except as below 1990-1998 1999-2010 L - Series 2000-2005 Vue 2002 2003-2009 Ion Redline Engine Cooling System Supercharger Cooling System	RA10036* RA10036* RA10034 RA10034 RA10036 RA10036 RA10056	RCA1C035 RCA1C035 RCA1C047 RCA1C047 RCA1C035 RCA1C035 RCA1C057

Make/Model/Year	Cooling System Adapter	Cap Adapter
SCION®		
All models 2004	RA10128	RCA1C029
XB 2008	RA10048	RCA1C049
SMART CAR®		
All models except below:		
2008-2015	RA10022	RCA1C023
2016-current	RA10063	RCA1C026
STERLING® All models		
1987-1991	RA10025	RCA1CO26
SUBARU®		
Models with 16mm deep		
filler neck, see page 9	RA10128	RCA1C029
Models with 9.5mm deep		
filler neck, see page 9	RA10138	RCA1C039
SUZUKI®	[
Models with 16mm deep		
filler neck Models with 9.5mm deep	RA10128	RCA1C029
filler neck EXCEPT BELOW:	RA10138	RCA1C039
Forenza 2004-2008	RA10034	RCA1C047
Reno 2005-2008	RA10034	RCA1C047
Verona 2004-2006	RA10034	RCA1C047
XL7		
2007-2009	RA10036	RCA1C035

* If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

Interactive Adapter search: www.mactoolsradiatortools.com

COOLING	51512	
Make/Model/Year	Cooling System Adapter	Cap Adapter
TESLA®		
Model 3		
2017-current	RA10098	RCA1C099
TOYOTA®		
Models with Non-Threaded		
Cooling System Caps:		
Models with 16mm deep		
filler neck, see page 9	RA10128	RCA1C029
Models with 9.5mm deep		
filler neck, see page 9	RA10138	RCA1C039
Models with Threaded		
Cooling System Caps:		
Celica		
2000-2005	RA10048	RCA1C049
MR2 Spyder		
2000-2005	RA10048	RCA1C049
RAV4		
1996-2008	RA10138	RCA1C039
2009-current	RA10048	RCA1C049
Sienna, see page 9		
1998-2006	RA10128R	RCA1C029
2007-current	RA10138	RCA1C039
Hybrid Synergy Drive		
Cooling System:		
Camry		
2007-current	RA10048	RCA1C049
Corolla		
2020-current	RA10048	RCA1C049
Highlander		54134949
2006-current	RA10048	RCA1C049
Prius 2004-current	RA10048	RCA1C049
TRUCKS/HEAV		INCAT CU47
Vehicles with large fill ("B")		
neck (2 11/16") see page 10	RA14505	RCA14504
VAN HOOL® B	US	
Some models	RA10076	
VOLKSWAGEN	D	
Models with male threads		
on filler neck		
1975-1993	RA10022	RCA1C023
Arteon 2019 - current Adata	RA10041	RCA1C040
Atlas 2018 - current Beetle	RA10041	RCA1C040
1998-current CC	RA10041	RCA1C040
2009-2013 Cabrio	RA10041	RCA1C040
1995-2002	RA10031	RCA1C030
Corrado 1990-1994	RA10031	RCA1C030

Make/Model/Year	Cooling System Adapter	Cap Adapter
VOLKSWAGEN®		, i
Eurovan 1993-2003 Golf	RA10031	RCA1C030
1991-1999 2000-current	RA10031 RA10041	RCA1C030 RCA1C040
GTI 1991-1999	RA10031	RCA1C030
2000-current Jetta	RA10041 RA10031	RCA1CO40 RCA1CO30
1991-1999 1999-current Passat	RA10031	RCA1C030 RCA1C040
1990-1997 1998-current	RA10031 RA10041	RCA1C030 RCA1C040
Phaeton 2002-2006	RA10074	RCA1C023
Tovareg 2004-current	RA10041	RCA1CO40
VOLVO®		
All with threaded neck		
except large trucks and as specified below	RA10025	RCA1C026
C30 2008-current C70	RA10052	RCA1C053
2008-current S40	RA10052	RCA1C053
2004-2011 S60	RA10052	RCA1C053
2011-current S80	RA10052	RCA1C053
2008-current V50	RA10052	RCA1C053
2005-2011 V60 2014 summert	RA10052 RA10052	RCA1C053
2014-current V70 2008-2010	RA10052	RCA1C053 RCA1C053
2008-2010 XC40 2018-current	RA10052	RCA1C053
XC60 2010-current	RA10052	RCA1C053
XC70 2008-current	RA10052	RCA1C053
XC90 T8 Hybrid 2016-current		
Engine Cooling System Battery Cooling System	RA10052 RA10088	RCA1C053 RCA1C089
Volvo® Large Trucks with:	B410000	BC41C000
48mm x 3mm thread 63mm x 3mm thread	RA10022 RA10027	RCA1CO23
	NATUUZ/	
Volvo® Heavy Equipment A45G Articulated Hauler		
2017-current EC220E Excavator	RA10094	
2015-current	RA10096	

 Laminated adapter application sheet included with both the CSA1700 and CSA1700A.
FITS RIGHT INSIDE THE CASE



CSA1700 COMPLETE AUTOMOTIVE COOLING SYSTEM TESTER:

CSA1700 will pressure test the cooling systems of all modern cars and light trucks through 2017. Includes UCT700-8 pump and the following 17 adapters: RA10022, RA10025, RA10031, RA10034, RA10036, RA10041, RA10044, RA10046, RA10048, RA10052, RA10056, RA10128, RA10138, RA10245, RA10345, RA10445, and RA14503. Does not cover 2007- Sprinter Van.

The **CSA1700A** is the above set of cooling system adapters without the UCT700-8 pump. If you are interested in a complete set of **CAP** adapters, see page 20.

CSCA1700: 17 Piece Cooling System <u>Cap</u> Adapter Set



* Compatible with most pressure pumps on the market.

* 17 Adapters (some multi purpose) test the 20 different pressure relieving <u>CAPS</u> found on cooling systems today.

* Adapters, where possible, are shaped to resemble the caps that they test, for example:



Adapters Included in the set are: RCA1C023, RCA1C026, RCA1C029, RCA1C030, RCA1C035, RCA1C039, RCA1C040, RCA1C045, RCA1C047, RCA1C049, RCA1C053, RCA1C057, RCA1C059, RCA1C346, RCA1C446, RCA14504, UCT700-6.


COOLING SYSTEM ADAPTER GASKET APPLICATION GUIDE

(Use gasket part # when ordering replacement gaskets)

ADAPTER	GASKET/O-RING SIZE	Gasket Part #
RA10034, RA10036	1 7/8" O.D. x 1 3/16" I.D. x 1/8" thick	RA10036G
RA10245, RA10345	1 7/16" O.D. x 15/16" I.D. x 1/16" thick	RA10345G
RA10128, RA10138	1 1/8" 0.D. x 1/2" I.D. x 1/4" thick	RA10128G
RA10031, RA10041, RA10074	36mm O.D. x 28mm I.D. x 4mm cross section O-ring	RA10041R
RA10032, RA10042	1 7/8" 0.D. x 1 1/16" I.D. x 1/8" thick	RA10032G
RA10036, RA10046, RA10052, RA10088, RA10092	31mm 0.D. x 23mm I.D. x 4mm cross section 0-ring	RA10036R
RA10044	42mm 0.D. x 34mm I.D. x 4mm cross section 0-ring	RA10044R
RA10048	13/16" 0.D. x 5/8" I.D. x 3/32" cross section 0-ring (0-ring # P	16) RA10048R
RA10056, RA10098	23mm 0.D. x 17mm I.D. x 3mm cross section 0-ring	RA10056R
RA10058	27mm 0.D. x 21mm I.D. x 3mm cross section 0-ring	RA10058R
RA10445	38mm 0.D. x 28mm I.D. x 5mm cross section O-ring	RA10445R
RA14503	2 3/4" 0.D. x 1 3/4" I.D. x 3/16" thick	RA14502
RA14505	Molded Rubber Gasket	RA14501
RA10025, RA10096	1 11/16" O.D. x 1 1/16" I.D. x 1/8" thick	RA10025G
RA10022	1 3/4" 0.D. x 1" I.D. x 1/8" thick	RA10022G
RA10027	2 3/8" O.D. x 1 5/8" I.D. x 1/8" thick	RA10027G
RA10054	2 1/4" O.D. x 1 1/2" I.D. x 1/8" thick	RA10054G
RA10063, RA10078	1 7/16" O.D. x 1 3/16" I.D. x 1/8" cross section O-ring	RA10063R
RA10067, RA10067R	Molded Rubber Gasket	RA10067G
RA10069	1" O.D. x 5/8" I.D. x 3/16" thick	RA10069G
RA10070	1" O.D. x 1/2" I.D. x 1/16" thick	RA10070G
RA10072	26mm O.D. x 19mm I.D. x 3.5mm cross section O-ring	RA10072R
RA10076	Molded Rubber Gasket (custom)	RA10076G
RA10084, RA10094	2 1/16" O.D. x 1 1/8" I.D. x 1/8" thick	RA10084G
RA10086	21mm O.D. x 14mm I.D. x 7mm cross O-ring	RA10086R
RA10090	Molded Rubber Gasket (custom)	RA10090G
RA10093	27mm 0.D. x 19mm ID x 4mm cross section 0-ring	RA10093R
RA10096	1 1/2" 0.D. x 1" I.D. x 1/8" thick	RA10096G
RA10102	2 3/8" 0.D. x 2" 1.D. x 3/16" cross (#329)	

PAGE 20

MAR100 COOLANT RETAINER - PARTS DIAGRAM AND REPLACEMENT PART NUMBERS -




Number	Part Number	Description
1	MAR100-1	Dual Gauge
2	MAR100-2	Hook Assembly with Nut
3	MAR100-3	Venturi Body
4	MAR100-4	Air Inlet Valve
5	MAR100-5	Brass GHT cap
6	MAR100-6	Intake Hose with Cap Assembly
7	MAR100-7	Exhaust Hose
Not Shown	MAR100-8	Plastic Box

TOOLS

CST300 PARTS LIST

Diagram #	Stock Part #	Description
Not Shown	UCT700-7	Plastic Carrying Case
*	CST300-1	Complete Pump w/Gauge
		& Hose Assy. (1-4)
1	UCT700-1	Pressure Gauge only
2	CST300-2	Valve Regulator Assy.
3	CST300-3	Tester Head w/Hose
		Assembly
4	UCT700-5	Tester Seal
5	UCT700-6	Cooling System Cap
		Adapter (A-size)
6	RCA14504	Cooling System Cap
		Adapter (B-size)
7	RCA1C035	Cooling System Cap
		Adapter (52mm x 2.5mm)



NOTES:			

	CST500 (Cooling System Tester
DIAGRAM #	STOCK PART#	DESCRIPTION
*	UCT700-8	Cooling System Tester Pump (Diagram #1–5) - Packed in a cardboard box.
not shown	UCT700-7	Plastic Carrying Case
		, .
1	UCT700-1	Heavy Duty Pressure Gauge with Rubber Boot
1 2	UCT700-1 UCT700-2	
		with Rubber Boot Pump Assembly with Knob
2	UCT700-2	with Rubber Boot Pump Assembly with Knob (gauge not included)
2 3	UCT700-2 UCT700-3	with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use
2 3 4	UCT700-2 UCT700-3 UCT700-4	with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use 3/16" ID fuel hose
2 3 4 5	UCT700-2 UCT700-3 UCT700-4 UCT700-5	with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use 3/16" ID fuel hose Tester Seal 32 mm x 16mm deep Radiator Adapter with Seal, Silver 32 mm x 9.5mm deep
2 3 4 5 7	UCT700-2 UCT700-3 UCT700-4 UCT700-5 RA10128	with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use 3/16" ID fuel hose Tester Seal 32 mm x 16mm deep Radiator Adapter with Seal, Silver
2 3 4 5 7 8	UCT700-2 UCT700-3 UCT700-4 UCT700-5 RA10128 RA10138	with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use 3/16" ID fuel hose Tester Seal 32 mm x 16mm deep Radiator Adapter with Seal, Silver 32 mm x 9.5mm deep Radiator Adapter with Seal, Gold Rubber Seal for 32mm
2 3 4 5 7 8 9	UCT700-2 UCT700-3 UCT700-4 UCT700-5 RA10128 RA10138 RA10128G	with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use 3/16" ID fuel hose Tester Seal 32 mm x 16mm deep Radiator Adapter with Seal, Silver 32 mm x 9.5mm deep Radiator Adapter with Seal, Gold Rubber Seal for 32mm Radiator Adapters

CAUTION: TO AVOID PERSONAL INJURY AND/OR VEHICLE DAMAGE – While some precautions are specified in this manual, and should be noted to avoid personal injury or vehicle damage, it is not possible for these cautions to cover all conceivable ways in which service or testing might be done, or all possible hazardous consequences of each way, nor could Mac Tools® possibly know or investigate all such ways. It is therefore the responsibility of anyone using this manual, to satisfy him or herself completely that neither personal safety or vehicle safety will be jeopardized by the service methods selected. Any such injury or damage is entirely the user's responsibility. This device is not to be used in any manner on the human body.

© 2020 Marvac Scientific Mfg. Co. All rights reserved