### Interactive Adapter search: www.mactoolsradiatortools.com



**COOLING SYSTEM ADAPTERS and COOLING SYSTEM TOOLS APPLICATION GUIDE** and **PARTS LIST** for

SCAN THIS CODE






MAR300 Refiller, Pressure Tester and Coolant Retainer all in one!



**CSR202** For Use with Positive Fit Cooling System Adapters





CSR302 No Adapters Required!

## COOLING SYSTEM TOOLS FOR LARGE TRUCKS



#### CSR400 Large Truck Refiller

- New higher capacity generator creates a high vacuum quickly.
- Larger internal passageways to move more coolant faster
- Longer and larger hoses improve coolant flow
- Faster, more complete fill on larger systems

**CSR400** Truck Refiller sized specifically for large trucks

#### CST300 Large Truck Cooling System Pressure Tester:

1. Pressure pump uses shop air to generate pressure in large truck cooling systems EFFORTLESSLY!

2. Set includes 3 adapters to pressure test pressure relieving caps found on large trucks. The UCT700-6 cap adapter tests caps from "A" size (2 3/16" O.D.) filler necks. The RCA14504 cap adapter tests caps from "B" size (2 11/16" O.D.) filler necks. The RCA1C035 cap adapter tests caps with a 52mm x 2.5mm thread.



#### Combine CST300 with CSA600 for complete truck cooling system testing with no duplications.

#### CSA600 Large Truck Cooling System Adapter Set:

Compatible with most cooling system pressure tester pumps. Includes 6 cooling system adapters:

(1) RA14505 (2) RA10036

(3) RA10027

(4) RA10022 (5) RA10054 (6) RA10032 NOTE: Plastic box available separately #CSA600PB



# Vacuum Holding Adapters

Large trucks often have two colling system caps located on the expansion tank: an accessible, non-pressure relieving cap and a pressure relieving cap that will leak under vacuum (normally found on the side of the tank).

RA10052V



50 x 2.5 mm



RA10025V

### RA10036V



45 x 3 mm



48 x 3 mm



52 x 2.5 mm

In order to put the cooling system under vaccumn to service the cooling system, a vacumn-holding adapter may be necessary. These adapters replace the pressure-relieving cap during the process and have an automatic safety pressure-relief system in case it is accientally left on.

The CSR400 large truck refiller is in a case that is designed with 4 molded recesses to store these adapters with the tool.



Thread Cutaway

#### **APPLICATION:**


AUDI®: models with male threads on filler neck PORSCHE®: Boxster: 1997-2006 Cayman: 2006 911: 2000-2012 SMART CAR®: Models 2008-2015 VOLKSWAGEN®: models with male threads on filler neck of radiator or expansion tank-pre 1990.

### RA10025




RCA1C026





#### APPLICATION:

FERRARI®/MASERATI®: most models 2000-current JEEP®: models with male threads on filler neck (1990-1994) RENAULT®: (1985-1997) SAAB® 900: (1978-1993) -900 Convertible (1994) -9000 (1986-1998) STERLING®: (1987-1991) VOLVO®: most models through 2007 with threaded neck (see page 18)



#### **APPLICATION:**


VOLKSWAGEN®: Most models with female threads on filler neck 1990-1998


RA10032





#### **APPLICATION:**

Some models of Buick®, Cadillac®, Chevrolet®, Ford®, Freightliner®, GMC®, International®, Infiniti®, Isuzu®, Jaguar®, Kenworth®, Land Rover®, Lincoln®, Mazda®, Mercedes-Benz®, Mercury<sup>®</sup>, Nissan<sup>®</sup>, Oldsmobile®, Peterbilt® and Pontiac®














RCA1C099

WHERE O-RING OF CAP SEALS IN COOLANT BOTTLE NECK



APPLICATION:

<u>TESLA</u>®: Tesla Model 3 Model Y






HYUNDAIR: Some sub-models of Santa Fe and Tucson KIA®: Some sub-models of Sorento. See page 14 (for HYUNDAI®) and 15 (for KIA®) for more specific applications

#### **APPLICATION:**

HYUNDAI®: Some sub-models of Santa Fe and Tucson KIA®: Carnival and K5 and some sub-models of Sorento and Sportage. See page 14 (for HYUNDAI®) and 15 (for KIA®) for more specific applications.



WHERE GASKET OF CAP SEALS ON **COOLANT BOTTLE NECK** Outside Diameter 52 mm -

WHERE GASKET OF CAP SEALS ON

OUTSIDE DIAMETER

32mm

2mm

thread

1


E oft hand 3mm

COOLANT BOTTLE NECK

32mm

WHERE GASKET OF CAP SEALS ON **COOLANT BOTTLE NECK** Outside Diameter 52 mm -4mm

WHERE GASKET OF CAP SEALS ON COOLANT BOTTLE NECK



#### APPLICATION:

HYUNDAI®: Ionig Electric and Kona Electric KIA®: Niro Hybrid and Plug-in. See page 14 for (HYUNDAI®) and 15 (for KIA®) for specific applications

#### **APPLICATION:**

BMW® models with threaded filler necks (up to 1987) 325: up to 1991 525: up to 1993 MERKUR® SCORPIO: (1987 - 1989)Comments: Rubber gasket seals on "shelf" inside expansion tank neck

#### APPLICATION:

BMW®: Most Models, 1998-2008

LAND ROVER®: Some models with male threads on filler neck (see page 15) Discovery 1999-2004 Range Rover 1996-2006 Comments: Rubber aasket seals on "shelf" inside expansion tank neck

> **APPLICATION:** BMW®: Most BMW models.

2007-current 3-Series 2006-current 5-Series 2005-current 6-Series 2005-current X3 2009-current X5 2009-current X6 2008-current


TOYOTA®: Supra 2020 - current

RCA1C446






#### MOST ASIAN VEHICLES - MOTORCYCLES - FORKLIFTS - TOYOTA® SIENNA VAN





Comments: The RA10128/RCA1C029 and the RA10138/RCA1C039 have applications too numerous to list here. See Application Guide pp 12-18. These adapter sets are quite similar, but the RA10128/RCA1C029 is a deeper neck than the RA10138/RCA1C039. See drawings above, right.


#### Note: RA10128 AND RA10138 are shaped to resemble caps from system to be tested.



#### **APPLICATION:**

Most passenger vehicles through the mid 1980's have this radiator neck and many still do today. This is the configuration onto which the pump attaches directly.

### LARGE TRUCKS / BUSES / HEAVY EQUIPMENT





Interactive Adapter search: www.mactoolsradiatortools.com

COOLING	JIJILA	AVALI
Make/Model/Year	Cooling System Adapter	Cap Adapter
ACURA®		
Models with 16mm deep filler neck, see page 9	RA10128	RCA1C029
Models with 9.5mm deep filler neck, see page 9	RA10138	RCA1C039
ALFA ROMEO®		
Some models 2014-current	RA10072**	RCA1CO26
ASTON MARTIN	N®	
6.0L, V-12		
2015-current	RA10052	RCA1C05
Various Models 2005-current	RA10046	RCA1C047
	KA10040	KCA1C047
AUDI®		
Models with male threads on filler neck of exp. tank	RA10022	RCA1C023
Models with female threads		
on filler neck of exp. tank	RA10041	RCA1CO40
<b>BLUEBIRD® BUS</b>	; 	
Late model Thomas Built		
buses	RA10036	RCA1CO35
BMW®		
Models with threaded		
Models with threaded filler neck		
Up to 1987	RA10245	RCA1C047
1988 & Newer,	KATU24J	KCATCU47
(except as noted)	RA10345	RCA1C346
Most models after 2006	RA10445	RCA1C446
Model 325		
1988-1991 Model 535	RA10245	RCA1CO47
1989-1993	RA10245	RCA1CO47
5&6 Series 2005-current	RA10445	RCA1C446
1 Series	INTO TO TO	RCAT CTTO
2008-current 3 Series	RA10445	RCA1C446
3 Series 1990-2006	RA10345	RCA1C346
2005-current	RA10345 RA10445	RCA1C346 RCA1C446
Turbocharger cooling sys (all)		RCA1C026
5 Series		
1998-2004	RA10345	RCA1C346
2005-current	RA10445	RCA1C446
Turbocharger cooling sys (all)	RA10063▲	RCA1C026
6 Series		
2004-current	RA10445	RCA1C446
Turbocharger cooling sys (all)	RA10063▲	RCA1CO26
7 Series	P410045	DC41/04/
1994-2008	RA10345	RCA1C346
2008-current	RA10445	RCA1C446
Turbocharger cooling sys (all)	RA10063▲	RCA1C026
		I I

Make/Model/Year	Cooling System Adapter	Cap Adapter
BMW®		
X1 2009-2011	RA10345	RCA1C346
X3 2004-7/2009 7/2009	RA10345 RA10445	RCA1C346 RCA1C446
X5 2000-2008	RA10345	RCA1C346
2009-current Turbocharger cooling sys (all) X6	RA10445 RA10063▲	RCA1C446 RCA1C026
2008-current Turbocharger cooling sys (all)	RA10445 RA10063▲	RCA1C446 RCA1C026
Z3 2002	RA10345	RCA1C346
Z4 2003-2008 2000 surrout	RA10345 RA10445	RCA1C346 RCA1C446
2009-current Z8 2003	RA10445	RCA1C446 RCA1C346
BUICK®		
All Models w/male threads		
on filler neck except as noted below	RA10036*	RCA1C035
Skyhawk 1982-1987 1.8L & 2.0L Skudarda	RA14503	
Skylark 1982-1988 2.5L 1992-1998	RA14503 RA10036*	RCA1C035
Somerset 1985-1987 2.5L CADILLAC®	RA14503	
All Models w/male threads		
on filler neck except as noted below	RA10036*	RCA1C035
Catera 1997- 2001 STS, CTS, ATS	RA10034	RCA1CO47
2005 -current Engine Cooling System Supercharger Cooling System	RA10036 RA10056	RCA1C035 RCA1C057
ooporanaigor coomig oysiani		
**PA10025 may also wo		

\*\*RA10025 may also work.

▲ RA10063 seals the same way the radiator cap seals but the RA10025 will work in most applications.

\*If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

Interactive Adapter search: www.mactoolsradiatortools.com

Сар

. Adapter

**Cooling System** 

Adapter

COOLING	JIJIEN	AVAFI	ERJ	ww
Make/Model/Year	Cooling System Adapter	Cap Adapter	Ма	ke/Model/Year
CHEVROLET®			CHR	YSLER®/DODO
All Models w/male threads			Pacific	a
on filler neck except as noted				17-current
below	RA10036*	RCA1C035	Eng	jine Cooling System
Aveo				ctric Motor
2004-2011	RA10034	RCA1CO47	Promo	
Beretta				14-current
1992-1996	RA10036*	RCA1C035		60 Pickup 87-1993
Bolt	B11005/	DC11C077	RAM 1	
2017-current	RA10056	RCA1C057		91-current
Citation 1982-1985 2.5L	RA14503			500 with eTorque
RA10056	RCA1C057			18-current
Cobalt	KCATCUS/		RAM P	ickup (threaded ca
2005-2010				expansion tank)
Engine Cooling System	RA10036	RCA1C035		13-current
Supercharger Cooling System		RCA1C057	Sebrin	
Impala				03-2005 6c 3.0L &
1994-1996	RA10036*	RCA1C035		2.4L
2004-current	RA10036	RCA1C035		01, 2002-2006 er Van
Lumina				er van 07-2010
1990-1992	RA14503		Stealt	
Metro				, 91-1996
1998-2001	RA10138	RCA1C039		s (3.0 liter only)
Nova	B410100	BC110000		01-2006
1985-1988	RA10128	RCA1C029	Summ	it
Prizm 1998-2002	RA10138	RCA1C039		89-1992
Silverado with Duramax	KATUT38	KCATCU39		92-1996
(L5P diesel) engine			Talon	00 1000
2017-2019 (pressure testing)	RA10092			90-1998
2017-2019 (vacuum filling)	RA10093			EWOO®
Spectrum				
1985-1989	RA10128	RCA1C029		99-2002
Sprint		NOTICOL/		IDT®
1985-1988	RA10128	RCA1C029	Series	900, 1000 and 110
Tracker			FER	RARI®
1998-2004	RA10138	RCA1C039		Aodels
Volt				00-current
2012-current		B 4 1 4 4 5 7	FIA	
Electric Motor	RA10056	RCA1C057	500	
Battery System	RA10056 RA10036	RCA1C057 RCA1C035	1 1 2 2 2 2	15-current
Gasoline Engine				RD®/LINCO
CHRYSLER®/DODGE@	Ø/EAGLE®/PLYMO	DUTH®/RAM®		dels w/male thread
200				dels w/male thread er neck except as not
2015-current	RA10036	RCA1C035	below	er neck except as not
1500 with eTorque		B 4 1 4 4 5 7		
2018 - current	RA10056	RCA1C057	Aspire	
2000 GTX	DA10100	DC41C000		94-1997
1989-1990	RA10128	RCA1C029	C-Max	
Avenger 1995-1999	RA10128	RCA1C029	Contou	13-current
Colt	INTO 120	NCATCO27		95-1997
1984-1993	RA10128	RCA1C029		98-2000
1992-1994 (some models)		RCA1C039		r/Thunderbird
Conquest				89-1992
1984-1989	RA10128	RCA1C029	19	93-1997 V8
Crossfire			19	93-1997 V6
2004-2008	RA10044	RCA1CO45	Ecospo	
Dart	B11000/	BC11 COOF		13-current
2013-current	RA10036	RCA1CO35	Edge	
Laser/Talon 1990-1998	PA10120	PCA1C020	20	15-current
**PA10025 will work in	RA10128	RCA1C029		

\*\*RA10025 will work in most applications

\* If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

	1	
CHRYSLER®/DODGE®	7EAGLE®/PLYMO	UTH®/RAM®
Pacifica		
2017-current	RA10036	RCA1C035
Engine Cooling System Electric Motor	RA10056	RCA1C035
Promaster	KATUUJO	KCATCU57
2014-current	RA10072**	RCA1C026
RAM 50 Pickup	KA10072	KCATCO20
1987-1993	RA10128	RCA1C029
RAM 1500	NATOT20	NCAT COL7
1991-current	none	UCT700
RAM 1500 with eTorque	nono	001700
2018-current	RA10056	RCA1C057
RAM Pickup (threaded cap		
on expansion tank)		
2013-current	RA10036	RCA1C035
Sebring		
2003-2005 6c 3.0L &	RA10138	RCA1C039
4c 2.4L		
2001, 2002-2006	none	UCT700-6
Sprinter Van		
2007-2010	RA10058	RCA1C059
Stealth		
1991-1996	RA10128	RCA1C029
Stratus (3.0 liter only)		
2001-2006	RA10138	RCA1C039
Summit		
1989-1992	RA10128	RCA1C029
1992-1996	RA10138	RCA1C039
Talon		
1990-1998	RA10128	RCA1C029
DAEWOO®		
All		
1999-2002	RA10034	RCA1C047
FENDT®		
	RA10108	
Series 900, 1000 and 1100	RA10108	
	RA10108	
Series 900, 1000 and 1100	RA10108	
Series 900, 1000 and 1100 FERRARI®	RA10108 RA10025	RCA1CO26
Series 900, 1000 and 1100 FERRARI® Most Models		RCA1CO26
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT®		RCA1CO26
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500	RA10025	
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current	RA10025 RA10072**	RCA1C026
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL	RA10025 RA10072**	RCA1C026
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads	RA10025 RA10072**	RCA1C026
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted	RA10025 RA10072** N@/MERCUR	RCA1C026 Y®
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads	RA10025 RA10072**	RCA1C026
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below	RA10025 RA10072** N@/MERCUR	RCA1C026 Y®
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire	RA10025 RA10072** N@/MERCUR	RCA1C026 Y@ RCA1C035
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997	RA10025 RA10072** N@/MERCUR RA10036*	RCA1C026 Y®
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire	RA10025 RA10072** N@/MERCUR RA10036*	RCA1C026 Y@ RCA1C035
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current	RA10025 RA10072** N@/MERCUR RA10036* RA10128	RCA1C026 Y@ RCA1C035 RCA1C029
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour	RA10025 RA10072** N@/MERCUR RA10036* RA10128 RA10052	RCA1C026 Y@ RCA1C035 RCA1C029 RCA1C053
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOLL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997	RA10025 RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10052	RCA1C026 Y® RCA1C035 RCA1C029 RCA1C053 RCA1C047
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000	RA10025 RA10072** N@/MERCUR RA10036* RA10128 RA10052	RCA1C026 Y@ RCA1C035 RCA1C029 RCA1C053
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filter neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1985-2000 Cougar/Thunderbird	RA10025 RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10034 RA10046	RCA1C026 (CA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992	RA10025 RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10034 RA10034 RA10034 RA10128	RCA1C026 CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C047 RCA1C029
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1988-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8	RA10025 RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10034 RA10046 RA10128 RA10036*	RCA1C026 (CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029 RCA1C029
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1998-1992 1993-1997 V8 1993-1997 V8	RA10025 RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10034 RA10034 RA10034 RA10128	RCA1C026 (CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C047 RCA1C029
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8 1993-1997 V8 1993-1997 V6 Ecosport	RA10025 RA10072** N@/MERCUR RA10036* RA10128 RA10034 RA10034 RA10034 RA10036* RA10036* RA10128 RA10036*	RCA1C026 © RCA1C035 RCA1C029 RCA1C029 RCA1C047 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FOD®/LINCOL All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1985-1997 1988-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8 1993-1997 V8 1993-1997 V6 Ecosport 2013-current	RA10025 RA10072** N@/MERCUR RA10036* RA10128 RA10052 RA10034 RA10034 RA10046 RA10128 RA10036*	RCA1C026 (CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029
Series 900, 1000 and 1100 <b>FERRARI®</b> Most Models 2000-current <b>FIAT®</b> 500 2015-current <b>FORD®/LINCOLI</b> All Models w/male threads on filler neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8 1993-1997 V8 1993-1997 V6 Ecosport 2013-current Edge	RA10025 RA10072** N@/MERCUR RA10036* RA10128 RA10034 RA10034 RA10034 RA10036* RA10128 RA10036* RA10128 RA10052	RCA1C026 (CA1C035 RCA1C035 RCA1C029 RCA1C053 RCA1C047 RCA1C047 RCA1C029 RCA1C035 RCA1C029 RCA1C029 RCA1C029 RCA1C029
Series 900, 1000 and 1100 FERRARI® Most Models 2000-current FIAT® 500 2015-current FORD@/LINCOL All Models w/male threads on filder neck except as noted below Aspire 1994-1997 C-Max 2013-current Contour 1995-1997 1998-2000 Cougar/Thunderbird 1989-1992 1993-1997 V8 1993-1997 V8 1993-1997 V6 Ecosport 2013-current	RA10025 RA10072** N@/MERCUR RA10036* RA10128 RA10034 RA10034 RA10034 RA10036* RA10036* RA10128 RA10036*	RCA1C026 © RCA1C035 RCA1C029 RCA1C029 RCA1C047 RCA1C047 RCA1C047 RCA1C029 RCA1C029 RCA1C029

COOLING	5151EM	ADAPI
Make/Model/Year	Cooling System Adapter	Cap Adapter
FORD®/LINCOL	N®/MERCUR	Y®
Escape		
2001-2012	RA10046	RCA1CO47
2013-current	RA10052	RCA1C053
Escort/Tracer		
1991-2012	RA10128	RCA1CO29
Explorer/Mountaineer/Aviator 1995-2002		RCA1C029
2002-current	RA10128 RA10036*	RCA1C029
F Series pick-up	KAT0030	KCATCUJJ
2015-current	RA10052	RCA1C053
Festiva		
1988-1993	RA10128	RCA1C029
Fiesta		
2011-current	RA10052	RCA1C053
Focus		
2000-2004	RA10034	RCA1CO47
2005-2007 2008-2011	RA10036* RA10128	RCA1C035 RCA1C029
2008-2011 2012-current	RA10052	RCA1C027
Fusion	NATOUJZ	RCATCO33
2006-2012	RA10036*	RCA1C035
2013-current	RA10052	RCA1C053
LS		
2002-2006	RA10034	RCA1C047
МКС		
2015-current	RA10052	RCA1C053
Mustang	B41000/*	DC11C005
V8, 1996-2014	RA10036*	RCA1C035
V6, 1997-2004 V6, 2005-2014	RA10128 RA10036*	RCA1C029 RCA1C035
V6 and V8 2015-current	RA10050	RCA1C053
Probe	INT 0052	NCAT COSO
1989-1997	RA10128	RCA1C029
Ranger Pickup		
1995-current		
(non threaded neck)	RA10128	RCA1C029
2002-current		
(threaded neck)	RA10036*	RCA1C035
Super Duty Pick-up		
2012-current expansion tank	RA10032	RCA1C035
Intercooler	RA10032	RCA1C033
Tempo/Topaz	NAT0120	RCATCO27
1992-1994	RA10128	RCA1C029
Thunderbird		
1989-1993 (All)	RA10128	RCA1C029
1994-1997 (V6)	RA10128	RCA1C029
1994-1997 (V8)	RA10036*	RCA1C035
2002-2004 (V8)	RA10036*	RCA1C035
Transit Connect	D410004	DC11C047
2010-2012 2012 summent	RA10034	RCA1C047
2013-current Villager	RA10052	RCA1C053
1993-2002	RA10128	RCA1C029
Windstar	10110120	
1995-2000	RA10128	RCA1C029
2000-2003	RA10036*	RCA1C035
ZX2		
2001-2003	RA10128	RCA1C029
If RA10036 "Stem" with 0	D-ring will not fit into	o cooling system

\* If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

#### Interactive Adapter search: www.mactoolsradiatortools.com

www.mactoolsradiatortools.com		
Make/Model/Year	Cooling System Adapter	Cap Adapter
<b>FREIGHTLINER</b> ®		
Trucks with: 60mm x 3mm male thread 52mm x 2.5mm male thread	RA10054	
Cascadia 2007-current Century, Columbia	RA10032	RCA1C035
2002-current	RA10036	RCA1CO35
<b>GEO</b> ®		
Metro		
1989-1994 1995-1998 Prizm	RA10128 RA10138	RCA1C029 RCA1C039
1989-1992 1993-2002	RA10128 RA10138	RCA1C029 RCA1C039
Storm 1990-1993 Tracker	RA10128	RCA1C029
1989-1993	RA10128	RCA1C029
1994-2004	RA10138	RCA1CO39
GMC®		
All Models w/male threads on filler neck Sierra w/ Duramax engine	RA10036	RCA1C035
2017-2019 (pressure testing)	RA10092	
2017-2019 (vacuum filling) 2020-current	RA10093	BCA10025
2020-current	RA10036 RA10056	RCA1C035 RCA1C057
HONDA®		
Models with 16mm deep	RA10128	RCA1C029
filler neck, see page 9		
Models with 9.5mm deep	RA10138	RCA1C039
filler neck, see page 9		
HUMMER®	l	
All Models w/male threads on filler neck	RA10036	RCA1CO35
HYUNDAI®	NAT0050	RCATCOJJ
Models with non-threaded cap	RA10128	RCA1C029
Elantra		
2016-current	RA10086	RCA1C0087
Ioniq, Electric	RA10110	RCA1C111
2020 Ionia	KATUTTU	KCATCITI
2017-2019 Kona, Electric	RA10086	RCA1C087
2019-2020	RA10110	RCA1C111
Kona (gasoline) 2020 Sante Fe	RA10086	RCA1C087
2021-current Santa Fe, Hybrid	RA10104	RCA1C105
2021-current Tucson 2.0L & 2.4L	RA10106	RCA1C107
2016-current Tucson 2.5L	RA10086	RCA1C087
2022-current Tucson Hybrid	RA10106	RCA1C107
2022-current Tucson, non-hybrid	RA10106	RCA1C107
2022-current	RA10104	RCA1C105

Coolina System Сар Make/Model/Year Adapter Adapter INDUSTRIAL Various industrial applications (see page 11 for specs) RA10090 **INTERNATIONAL®** 466 Engine with male threads on filler neck 1994-1998 RA10032 RCA1C035 **INFINITI®** All Models with Non-Threaded Small Cooling System Caps (see page 9) RA10128 **RCA1C029** QX30 RA10044 2017-current RCA1C045 QX50 2019 - current RA10063 RCA1C026 QX56 2004-2009 RA10036\* RCA1C035 2010-current RA10128 RCA1C029 **ISUZU**® All models except as noted below 1985-2009 RA10128 RCA1C029 Amigo 1999-2000 (L-4 only) RA10138 RCA1C039 Ascender 2002-2009 RA10036 RCA1C035 i280 2006 RA10036 RCA1C035 i290 2007-2008 RA10036 RCA1C035 i350 RA10036 RCA1C035 2006 i370 2007-2008 RA10036 RCA1C035 Oasis 1996-1999 RA10138 RCA1C039 Rodeo RA10138 RCA1C039 1998-2003 (L-4 only) **JAGUAR**® Models with male threads on filler neck 1990-1994 RA10034 RCA1C047 F-Pace 2018-current RCA1C053 RA10052 F-Type 2013-current RA10036 RCA1C035 XF 2009-current RA10036\* RCA1C035 X 18 1998-2003 RA10046 RCA1C047 RCA1C035 2004-2009 RA10036\* XK8 1997-2004, 2006 RA10046 RCA1C047 S-Type RA10036\* RCA1C035 2000-2008 X-Type 2002-2009 RA10034 RCA1C047

\* If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

#### Interactive Adapter search: www.mactoolsradiatortools.com

www.mactoolsradiatortools.com		
Make/Model/Year	Cooling System Adapter	Cap Adapter
JEEP®		
JEEP(9) Models with male threads on filler neck 1987-1990 Cherokee 2014-current 2015-current Wrangler 2018-current With eTorque 2018-current JOHN DEERE(8) T Most model #'s over 3000 with 48mm 0.D. male threads on filler neck Some model #'s over 3000	RA10025 RA10036 RA10036 RA10036 RA10056 <b>RACTORS</b> RA10022	RCA1C026 RCA1C035 RCA1C035 RCA1C035 RCA1C035 RCA1C057
with 52mm O.D. male threads on filler neck Some Models	RA10102 RA10102	N/A
KENWORTH® TR	UCKS	
Some Models 2007-current 1270, 1370 2015-current 1660 2008-2017 1680 2014-current	RA10032 RA10084 RA10042 RA10042	RCA1C035
KIA®		
Models with non-threaded cap Carnival 2022-current K5 2021-current Niro EV 2019-current 2017-current Settos 1.6L 2021-current Sorento Hybrid 2021-current Sorento Hybrid 2021-current Sorento Hybrid 2021-current Sovertage 2.0L & 2.4L 2021-current Sportage 2.0L & 2.4L 2021-current Sportage 2.5L 2022-current	RA10128 RA10106 RA10106 RA10086 RA10086 RA10104 RA10106 RA10106 RA10106	RCA1C029 RCA1C107 RCA1C107 RCA1C111 RCA1C087 RCA1C087 RCA1C105 RCA1C107 RCA1C107 RCA1C107

**Cooling System** Сар Make/Model/Year Adapter Adapter LAND ROVER® Defender RA10034 RCA1C047 1993-1995, 1997 Discovery 1998 RA10034 RCA1C047 1999-2004 RA10345 RCA1C346 Freelander 2002-current RA10025 RCA1C026 LR2 RA10052 2008-current RCA1C053 LR3 2005-2009 RA10036\* RCA1C035 LR4 2010-2016 RA10036\* RCA1C035 **Range Rover** RA10034 1988-1994 RCA1C047 RCA1C346 1995-2005 RA10345 2006-2015 RA10036\* RCA1C035 Ranae Rover Evoque 2012-current RA10052 RCA1C053 Velar 2018-current RA10032 RCA1C035 **LEXUS**® Models with 16mm deep filler neck, see page 9 RA10128 **RCA1C029** Models with 9.5mm deep filler neck, see page 9 RA10138 RCA1C039 Models with Threaded Caps: GS 460 RA10048 RCA1C049 2008-2011 HS 250h 2010-current RA10048 RCA1C049 IS F RA10048 RCA1C049 2008-2014 LS RA10048 RCA1C049 2007-current NX 2015-current RA10048 RCA1C049 LIEBHERR® CRANE RA10076 Some models MACK® Late models with male threads on filler neck RA10022 RCA1C023 w/6.7L Cummins engine 2022-current RA10096 MASERATI® Most Models 2000-current RA10025 RCA1C026 Ghilbi S Q4 2015-current RA10072\*\* RCA1C026 MAZDA® Models with 16mm deep RA10128 RCA1C029 filler neck, see page 9 Models with 9.5mm deep RA10138 filler neck, see page 9 RCA1C039 Models with Threaded Caps: B2300 Pickup 1994-1997 UCT700-6 none 2001-2009 RA10036\* RCA1C035 Tribute 2001-2011 RA10046 RCA1C047 Mazda 3 2004-current RA10052 RCA1C053 Mazda 6 2003-current RA10036 RCA1C035

#### Interactive Adapter search: www.mactoolsradiatortools.com

www.macrooisraalafortoois.com		
Make/Model/Year	Cooling System Adapter	Cap Adapter
McLAREN®		
Most Models 2012-current	RA10072	RCA1C026
MERCEDES-BEN	Z®	
Models with threaded neck except M-Class below	RA10044	RCA1CO45
A-Class 2019-current B-Class	RA10058	RCA1C059
2015-current M-Class with threaded neck	RA10058	RCA1C059
1998-2005 M-Class	RA10036*	RCA1C035
2006-current Sprinter	RA10044	RCA1C045
2018-current 2019-current	RA10058 RA10044	RCA1C059 RCA1C045
MERKUR®		
Scorpio 1987-1989	RA10245	RCA1CO47
MINI®		
Cooper S Model 2002-current	RA10063▲	RCA1C026
MITSUBISHI®		
Models with 16mm deep filler neck, see page 9 Models with 9.5mm deep	RA10128	RCA1C029
filler neck, see page 9	RA10138	RCA1C039
NISSAN®		
All models with non-threaded		
small cooling system caps 1987-current Armada/Titan	RA10128	RCA1C029
2004-2009	RA10036*	RCA1C035
2010-2015	RA10128	RCA1C029
Kicks 2019-current Rogue Sport	RA10063	RCA1C026
2017-current Rogue	RA10063	RCA1C026
2021-current	RA10063	RCA1C026
OLDSMOBILE®		
Achieva 1992-1998	RA10036*	RCA1C035
Alero 1999-2004 Aurora	RA10036	RCA1C035
1995-1999 Bravada	RA10036*	RCA1C035
2002-2004 Cutlass	RA10036	RCA1C035
1997-1998 1999-2004 Intrigue	RA10036* RA10036	RCA1C035 RCA1C035
1999-2002	RA10036*	RCA1C035

▲ RA10063 seals the same way the radiator cap seals but the RA10025 will work in most applications.

\* If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

\*\*RA10025 will work in most applications

PAGE 16

Interactive Adapter search: www.mactoolsradiatortools.com

Make/Model/Year	Cooling System Adapter	Cap Adapter
PETERBILT® TRU		
Some Models 2007-current	RA10032	
Fiero		
1984-1988	RA14503	
Firebird 1999-2002	RA10036	RCA1C035
G3 2009-2010	RA10034	RCA1C047
G5		
2007-2012 G6	RA10036	RCA1C035
2005-2010 Grand Am	RA10036	RCA1C035
1985-1988 1992-2005	RA14503 RA10036*	RCA1C035
Grand Prix 2004-2008	RA10036	RCA1C035
GTO 2004-2008	RA10036*	RCA1C035
Le Mans		
1988-1993 Montana	RA10034	RCA1C047
1999-2006 2007-2009	none RA10036	UCT700-6 RCA1C035
Optima 1988-1991	RA10036*	RCA1C035
Solstice 2006-2009	RA10036	RCA1C035
Sunbird 1982-1992	RA14503	
Sunburst 1985-1988	RA10128	RCA1C029
Sunfire 1995-1998	RA10036*	RCA1C035
1999-2005 Vibe	RA10036	RCA1C035
2003-2013	RA10138	RCA1C039
PORSCHE® 911	[	
1999-current	RA10022	RCA1C023
Boxster 1997-2006	RA10022	RCA1C023
2007-2013 2015-current	RA10041 RA10078	RCA1CO40
(in luggage compartment)	KA10070	
Cayenne 2003-current	RA10041	RCA1CO40
Cayman		
2006 2007-2011	RA10022 RA10041	RCA1C023 RCA1C040
2014-current	RA10078	
(in luggage compartment) Macan		
2015-current Panamera	RA10041	RCA1CO40
2010-current	RA10041	RCA1CO40
<b>RENAULT®</b>		
All models 1985-1987	RA10025	RCA1C026
		1

Make/Model/Year	Cooling System Adapter	Cap Adapter
ROLLS ROYCE®	1	
Ghost 2010	RA10445	RCA1C446
Engine cooling system	KA10445	KCA1C440
Supercharger cooling system	RA10063	RCA1CO26
SAAB®		
900		
1978-1993	RA10025	RCA1C026
1994-1998 900 Convertible	RA10034	RCA1CO47
1994	RA10025	RCA1C026
9000	D410005	DC41600/
1986-1998 9-3	RA10025	RCA1C026
1999-2003	RA10034	RCA1CO47
2004-2011	RA10036	RCA1C035
9-5 1999-2008	RA10034	RCA1C047
9-7X	ALLOUT.	
2005-2009	RA10036*	RCA1C035
SATURN®		
All models except as below 1990-1998	RA10036*	RCA1C035
1999-2010	RA10036*	RCA1C035
L - Series		
2000-2005 Vue	RA10034	RCA1CO47
2002	RA10034	RCA1C047
2003-2009	RA10036	RCA1C035
Ion Redline Engine Cooling System	RA10036	RCA1C035
Supercharger	KA10030	KCATCU35
Cooling System	RA10056	RCA1C057
SCION®		
All models except below	RA10128	RCA1C029
XB 2008	RA10048	RCA1C049
SMART CAR®	INTO IS	Refrectiv
All models except below:		
2008-2015	RA10022	RCA1C023
2016-current	RA10063	RCA1C026
STERLING®	[	
All models 1987-1991	RA10025	RCA1C026
SUBARU®	IAT 0025	Refreded
Models with 16mm deep		
filler neck, see page 9	RA10128	RCA1C029
Models with 9.5mm deep filler neck, see page 9	RA10138	RCA1C039
SUZUKI®		
Models with 16mm deep		
filler neck	RA10128	RCA1C029
Models with 9.5mm deep filler neck EXCEPT BELOW:	RA10138	RCA1C039
Forenza		
2004-2008 Pene	RA10034	RCA1CO47
Reno 2005-2008	RA10034	RCA1C047
Verona		
2004-2006 XL7	RA10034	RCA1CO47
2007-2009	RA10036	RCA1C035

\* If RA10036 "Stem" with O-ring will not fit into cooling system neck, the RA10032 may be required.

PAGE 17

COOLINO	51511	
Make/Model/Year	Cooling System Adapter	Cap Adapter
TESLA®		
Model 3		
2017-current	RA10098	RCA1C099
Model S		
2012-current	RA10036	RCA1C035
Model Y 2020-current	RA10098	BCA1C000
	KA10090	RCA1C099
TOYOTA® Models with Non-Threaded		
Cooling System Caps:		
Models with 16mm deep		
filler neck, see page 9	RA10128	RCA1C029
Models with 9.5mm deep		
filler neck, see page 9	RA10138	RCA1C039
Models with Threaded		
Cooling System Caps:		
Celica		
2000-2005	RA10048	RCA1C049
MR2 Spyder		
2000-2005	RA10048	RCA1C049
RAV4		
1996-2008	RA10138	RCA1C039
2009-current	RA10048	RCA1C037
Sienna, see page 9	10110010	NOTION/
1998-2006	RA10128R	RCA1C029
2007-current	RA10128K	RCA1C027
Supra	KATO150	RCATCO37
2020 - current	RA10445	RCA1C446
	KATUTTJ	REALCHIO
Hybrid Synergy Drive Cooling System:		
Cooning System. Camry		
2007-current	RA10048	RCA1C049
Corolla	KA10040	KCATC047
2020-current	RA10048	RCA1C049
	KA I UU40	KCATC049
Highlander	RA10048	RCA1C049
2006-current Prius	NA I UU40	KLAT LU49
2004-current	RA10048	RCA1C049
TRUCKS/HEAVY		
Vehicles with large fill ("B")		
neck (2 11/16") see page 10	RA14505	RCA14504
VAN HOOL® BU	IS	
Some models	RA10076	
VOLKSWAGEN		
Models with male threads		
on filler neck		
1975-1993	RA10022	RCA1C023
Arteon	PA10041	BCA1C040
2019 - current Atlas	RA10041	RCA1CO4O
2018 - current	RA10041	RCA1CO40
Beetle		
1998-current	RA10041	RCA1CO40
CC 2000 2017	PA10041	BCA1C040
2009-2017 Cabrio	RA10041	RCA1CO4O
1995-2002	RA10031	RCA1C030

S www.i	mactoolsradi	atortools.con
Make/Model/Year	Cooling System Adapter	Cap Adapter
VOLKSWAGEN®		1
Corrado 1990-1994	RA10031	RCA1C03
Eurovan		
1993-2003 Golf	RA10031	RCA1C030
1991-1999	RA10031	RCA1C030
2000-current	RA10041	RCA1C040
GTI 1991-1999	RA10031	RCA1C030
2000-current	RA10031	RCA1C030
Jetta	B410001	DC41 C000
1991-1999 1999-current	RA10031 RA10041	RCA1C030 RCA1C040
Passat		
1990-1997 1998-current	RA10031 RA10041	RCA1C030 RCA1C040
Phaeton		
2002-2006	RA10074	RCA1C023
Touareg 2004-current	RA10041	RCA1CO40
VOLVO®	1	1
All with threaded neck		
except large trucks and	BA10005	DCA1C09/
as specified below C30	RA10025	RCA1CO26
2008-current	RA10052	RCA1C053
C70 2008-current	RA10052	RCA1C053
S40		
2004-2011 S60	RA10052	RCA1C053
2011-current	RA10052	RCA1C053
S80 2008-current	RA10052	RCA1C053
V50		
2005-2011 V60	RA10052	RCA1C053
2014-current	RA10052	RCA1C053
V70 2008-2010	RA10052	RCA1C053
XC40	DA10000	DC41 C000
2018-current XC60	RA10088	RCA1C089
2010-current	RA10052	RCA1C053
XC70 2008-current	RA10052	RCA1C053
XC90 T8 Hybrid		
2016-current Engine Cooling System	RA10052	RCA1C053
Battery Cooling System	RA10088	RCA1C089
Volvo® Large Trucks with:		
48mm x 3mm thread	RA10022	RCA1C023
63mm x 3mm thread	RA10022 RA10027	
		ļ
Volvo® Heavy Equipment		
A45G Articulated Hauler		
2017-current	RA10094	
EC220E Excavator	PA10004	
2015-current	RA10096	

### Laminated adapter application sheet included with both the CSA1700 and CSA1700A. • FITS RIGHT INSIDE THE CASE •



### CSA1700 COMPLETE AUTOMOTIVE COOLING SYSTEM TESTER:

**CSA1700** will pressure test the cooling systems of all modern cars and light trucks through 2017. Includes UCT700-8 pump and the following 17 adapters: RA10022, RA10025, RA10031, RA10034, RA10036, RA10041, RA10044, RA10046, RA10048, RA10052, RA10056, RA10128, RA10138, RA10245, RA10345, RA10445, and RA14503.

Does not cover 2007 - 2018 Sprinter Van, Kia, Hyundai or hybrid Volvo.

The **CSA1700A** is the above set of cooling system adapters without the UCT700-8 pump. If you are interested in a complete set of **CAP** adapters, see page 20.

## CSCA1700: 17 Piece Cooling System <u>Cap</u> Adapter Set



\* Compatible with most pressure pumps on the market.

\* 17 Adapters (some multi purpose) test the 20 different pressure relieving <u>CAPS</u> found on cooling systems today.

\* Adapters, where possible, are shaped to resemble the caps that they test, for example:



Adapters Included in the set are: RCA1C023, RCA1C026, RCA1C029, RCA1C030, RCA1C035, RCA1C039, RCA1C040, RCA1C045, RCA1C047, RCA1C049, RCA1C053, RCA1C057, RCA1C059, RCA1C346, RCA1C446, RCA14504, UCT700-6.

### COOLING SYSTEM ADAPTER GASKET APPLICATION GUIDE

(Use gasket part # when ordering replacement gaskets)

ADAPTER	GASKET/O-RING SIZE GA	ASKET PART #
RA10034, RA10036	1 7/8" 0.D. x 1 3/16" I.D. x 1/8" thick	RA10036G
RA10245, RA10345	1 7/16" O.D. x 15/16" I.D. x 1/16" thick	RA10345G
RA10128, RA10138	1 1/8" 0.D. x 1/2" I.D. x 1/4" thick	RA10128G
RA10031, RA10041, RA10074	36mm 0.D. x 28mm I.D. x 4mm cross section O-ring	RA10041R
RA10032, RA10042	1 7/8" 0.D. x 1 1/16" I.D. x 1/8" thick	RA10032G
RA10036, RA10046, RA10052, RA10088, RA10092	31mm 0.D. x 23mm I.D. x 4mm cross section 0-ring	RA10036R
RA10044	42mm 0.D. x 34mm I.D. x 4mm cross section 0-ring	RA10044R
RA10048	13/16" O.D. x 5/8" I.D. x 3/32" cross section O-ring (O-ring # P16	) RA10048R
RA10056, RA10098	23mm 0.D. x 17mm I.D. x 3mm cross section 0-ring	RA10056R
RA10058	27mm 0.D. x 21mm I.D. x 3mm cross section 0-ring	RA10058R
RA10445	38mm O.D. x 28mm I.D. x 5mm cross section O-ring	RA10445R
RA14503	2 3/4" 0.D. x 1 3/4" I.D. x 3/16" thick	RA14502
RA14505	Molded Rubber Gasket	RA14501
RA10025, RA10096	1 11/16" O.D. x 1 1/16" I.D. x 1/8" thick	RA10025G
RA10022	1 3/4" O.D. x 1″ I.D. x 1/8" thick	RA10022G
RA10027	2 3/8" 0.D. x 1 5/8" I.D. x 1/8" thick	RA10027G
RA10054	2 1/4" 0.D. x 1 1/2" 1.D. x 1/8" thick	RA10054G
RA10063, RA10078	1 7/16" O.D. x 1 3/16" I.D. x 1/8" cross section O-ring	RA10063R
RA10067, RA10067R	Molded Rubber Gasket	RA10067G
RA10069	1″ O.D. x 5/8″ I.D. x 3/16″ thick	RA10069G
RA10070	1″ O.D. x 1/2″ I.D. x 1/16″ thick	RA10070G
RA10072	26mm 0.D. x 19mm I.D. x 3.5mm cross section 0-ring	RA10072R
RA10076	Molded Rubber Gasket (custom)	RA10076G
RA10084, RA10094	2 1/16" O.D. x 1 1/8" I.D. x 1/8" thick	RA10084G
RA10086	21mm O.D. x 14mm I.D. x 3.5mm cross O-ring	RA10086R
RA10090	Molded Rubber Gasket (custom)	RA10090G
RA10093	27mm 0.D. x 19mm ID x 4mm cross section 0-ring	RA10093R
RA10096	1 1/2" O.D. x 1" I.D. x 1/8" thick	RA10096G
RA10102	2 3/8" 0.D. x 2" 1.D. x 3/16" cross (#329)	Consult Factory

PAGE 20

### MAR300 COOLANT PRESSURE TESTER, REFILLER AND RETAINER - PARTS DIAGRAM AND REPLACEMENT PART NUMBERS -

3~0	Diagram# 1	Part # CSR202-2	Description Coolant Refill Body Assy
	9 2 4 5 6 7	UCT700-5 MAR100-1 CSR200-6 CSR400-3 MAR300-3 CSR400-4	Tester Seal Dual Gauge Isolation Valve Coolant Refill Valve Venturi Body Coolant Refill Hose with Screen
	8 9 10	MAR100-5 CSR200-7 CSR400-5	Brass GHT Cap Air Inlet Valve Coolant Refill Suction Screen Only
	*(not shown)	MAR300-7	Exhaust Hose


(not shown)

MAR300-7 \*(not shown) CSR400-10 Plastic Case



CST300 PARTS	LIST
	3 4
P B	B
5 6	7

Diagram #	Stock Part #	Description
Not Shown	UCT700-7	Plastic Carrying Case
*	CST300-1	Complete Pump w/Gauge
		& Hose Assy. (1-4)
1	UCT700-1	Pressure Gauge only
2	CST300-2	Valve Regulator Assy.
3	CST300-3	Tester Head w/Hose
		Assembly
4	UCT700-5	Tester Seal
5	UCT700-6	Cooling System Cap
		Adapter (A-size)
6	RCA14504	Cooling System Cap
		Adapter (B-size)
7	RCA1C035	Cooling System Cap
		Adapter (52mm x 2.5mm)



I	Vaximum Vacuum (inHg)	Flow (CFM)	Air consumption (CFM)	Refill Rate (Gal/Min)
CSR202	28.3	2.4	5.8	2.8
CSR302	28.3	2.4	5.8	2.8
CSR400	28.3	5.8	15.5	4.8
MAR300	28.1	8.1	17	4.8

Test performed using 100 - 110psi compressed air

Barometric pressure: 30.1 - 30.2

(For best results use 100psi regulated pressure input)



NOTES:

	CST500 (	Cooling System Tester
DIAGRAM #	STOCK PART#	DESCRIPTION
•	UCT700-8	Cooling System Tester Pump (Diagram #1–5) - Packed in a cardboard box.
not shown	UCT700-7	Plastic Carrying Case
1	UCT700-1	Heavy Duty Pressure Gauge with Rubber Boot
	UCT700-1 UCT700-2	Heavy Duty Pressure Gauge
1		Heavy Duty Pressure Gauge with Rubber Boot Pump Assembly with Knob
1 2	UCT700-2	Heavy Duty Pressure Gauge with Rubber Boot Pump Assembly with Knob (gauge not included)
1 2 3	UCT700-2 UCT700-3	Heavy Duty Pressure Gauge with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use
1 2 3 4	UCT700-2 UCT700-3 UCT700-4	Heavy Duty Pressure Gauge with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use 3/16" ID fuel hose
1 2 3 4 5	UCT700-2 UCT700-3 UCT700-4 UCT700-5	Heavy Duty Pressure Gauge with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use 3/16" ID fuel hose Tester Seal 32 mm x 16mm deep
1 2 3 4 5 7	UCT700-2 UCT700-3 UCT700-4 UCT700-5 RA10128	Heavy Duty Pressure Gauge with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use 3/16" ID fuel hose Tester Seal 32 mm x 16mm deep Radiator Adapter with Seal, Silver 32 mm x 9.5mm deep
1 2 3 4 5 7 8	UCT700-2 UCT700-3 UCT700-4 UCT700-5 RA10128 RA10138	Heavy Duty Pressure Gauge with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use 3/16" ID fuel hose Tester Seal 32 mm x 16mm deep Radiator Adapter with Seal, Silver 32 mm x 9.5mm deep Radiator Adapter with Seal, Gold Rubber Seal for 32mm
1 2 3 4 5 7 8 9	UCT700-2 UCT700-3 UCT700-4 UCT700-5 RA10128 RA10128G	Heavy Duty Pressure Gauge with Rubber Boot Pump Assembly with Knob (gauge not included) Knob Only Tester Head with Hose Assembly NOTE: Hose may be field repaired - use 3/16" ID fuel hose Tester Seal 32 mm x 16mm deep Radiator Adapter with Seal, Silver 32 mm x 9.5mm deep Radiator Adapter with Seal, Gold Rubber Seal for 32mm Radiator Adapters

CAUTION: TO AVOID PERSONAL INJURY AND/OR VEHICLE DAMAGE – While some precautions are specified in this manual, and should be noted to avoid personal injury or vehicle damage, it is not possible for these cautions to cover all conceivable ways in which service or testing might be done, or all possible hazardous consequences of each way, nor could Mac Tools® possibly know or investigate all such ways. It is therefore the responsibility of anyone using this manual, to satisfy him or herself completely that neither personal safety or vehicle safety will be jeopardized by the service methods selected. Any such injury or damage is entirely the user's responsibility. This device is not to be used in any manner on the human body.

© 2024 Marvac Scientific Mfg. Co. All rights reserved